



Geosatpro 1200 Update Instructions

1. On the GEOSATPRO Remote, press the Menu button
2. A blue screen that says Installation at the top should come up
3. Satellite Setup will have a yellow/orange bar through it.
4. Press the Down button 2 times til the yellow/orange bar is on Manual Scan
5. Press Ok button
6. A screen comes up with Satellite Ku-Galaxy 19 with a blue line through it;
Press the down arrow one time so that the blue line is through Frequency
7. Type in 12028 in the spot where it says 11842
8. Press Down arrow to Channel type
9. Press Right button and it will change from All to Free Only
(Make sure you have signal and quality above 60 percent (adjust dish if necessary))
10. Press the green button on your remote
11. The receiver will scan for the new channels and then jump out to one of your channels
12. Press OK; a channel list should come up
13. Press Down button and scroll through list and look for 3ABN S2; Press Ok Button,
(Channel will load), Press Exit button to remove channel list
When you find 3ABN S2, you will know your update was successful.

To delete miscellaneous unwanted channels

14. Press Menu
15. Press Right arrow once, click Channel. TV Channel Editor should be highlighted
16. Press OK Button
17. Push Down button to a channel you want to delete
18. Press the Yellow button on your remote; a box that says Delete Select will come up
19. Press OK button
20. This will put an X on the channel to delete.
21. Go down your list and press the Yellow button to add red Xs
22. To deselect a channel selected in error, just push the Yellow button again.

Channels to save

- 3ABN S2 (Transponder will say 10028)
- Amazing Facts TV HD (Transponder will say 12028)
- Amazing Discoveries (Transponder will say 12028)

- QVTV (Transponder will say 11842)
- FirstLight (an Adventist channel from New Zealand, Transponder 12028)
- LLBN-His Word TV (transponder will say 11842)
- Hope Channel (Transponder will say 11842)
- Esperanza TV (Transponder will say 11842)

23. When you have red Xs by all the channels you want to delete, Press OK button

24. It will say "Are you sure?" Press the OK button to save changes.

25. Then press Exit button to leave the delete menus

3ABN Support

10/16/23