



Koqit V5H H.265 Update Instructions

For viewers who did not receive a replacement receiver from 3ABN

Adding New Frequency

1. Press Menu button
2. Use the left/right, up/down arrow button surrounding the OK button to highlight Installation
3. Press OK button; a drop-down list will appear
4. With "Antenna Setting" highlighted, press OK button; this will change screens
5. On "Satellite" use the left/right buttons to find the Satellite Name "Galaxy_19_Ku"
This is usually about 20/76 in the list
6. Press Down arrow button twice to go to "LNB Frequency"
7. Use the left/right arrow buttons to choose 10750
8. Press Down arrow button four times to go to "TP"
9. Use left/right arrow buttons to choose 12028/H/2200
This is usually 5/12 in the list
10. Press Down arrow button once to go to Start Search
11. Use the left/right arrow button to choose TP
12. Press OK button
A TP Search screen will appear
13. Press Up arrow button three times to FTA ONLY
14. Use left/right arrow buttons to choose to Yes
15. Press Down arrow button three times to get to Search
16. Press OK button
This will start a scan
17. Once scan is complete, press Exit button until you return to Main TV screen

Verifying correct channels

1. Press OK Button for Channel List to appear
2. First channel will be highlighted. Press Down button until you see 3ABN S2
3. Once 3ABN is confirmed, update is successful. Press Exit button to return to main TV

Deleting Channels

1. Press OK Button for Channel list to appear
2. Press Yellow button to change screen to Channel Edit screen
3. Press 1 to enter delete mode. A red X should appear on Del
4. Press OK button on channels you want to delete. A red X will appear next to the channel you are deleting
5. When done deleting channels, press Exit button. A message will appear: "Do you want to save?"
6. Press the OK button. It will return you to drop down menu on Channel Edit
7. Press Exit button two times to return to main TV

September 14, 2023

3ABN Support